



LEAK OR JOINT REPAIR - SLAB TO SLAB

REFER TO APPLICATION INSTRUCTION 5.12